

Hand Control **HF**

HF handset has up to 10 buttons, compatible with many MOTECK furniture and medical care application control boxes.



Features and Option

- Main applications: Medical Care, furniture
- Available number of buttons: 10 max.
- IP Protection level: IPX4
- Color: Light gray (RAL 7035)
- LED indicator
- With hook for easy placement
- Cable length: Total 880mm long with 420mm spiral
- Optional larger gap hook (50mm)
- Optional safety key

1


Compatibility

Product	Compatible models	Compatible requirement
Control box	T control, CBT2, CB3T, CS1, CS2	- Moteck P1 control category - With Moteck F-type DIN plug
	CB2P, CB4P, CB4M, MD6C, MD7C, MD80M	- Moteck P1 control category - With Moteck V-type or H-type DIN plug
Double motor	TW41/61	- Moteck P1 control category - With Moteck A-type DIN plug

Cable plug











Dimensions

- HF




- With 50mm gap hook




Standard Panel Artwork

> Moteck control category P1 without position memory function

▶ Definition 1 (Artwork A, B, D, F, H, I)




▶ Definition 2 (Artwork C, E, J, K)




Button definition:


- Definition 1 (Artwork A, B, D, F, H, I)
- ① Actuator #1 extend
- ② Actuator #1 retract
- 3 Actuator #2 extend
- 4 Actuator #2 retract
- @ A t - t - #3 - t - -
- (5) Actuator #3 extend
- 6 Actuator #3 retract7 Actuator #4 extend
- 8 Actuator #4 retract




- Definition 2 (Artwork C, E, J, K)
 - ① Actuator #1 extend
 - 2 Actuator #1 retract
 - 3 Actuator #1 & #2 extend
 - 4 Actuator #1 & #2 retract
 - (5) Actuator #2 extend
 - 6 Actuator #2 retract
 - 7 Actuator #3 extend
 - 8 Actuator #3 retract




▶ Definition 3 (Artwork G)




- Definition 3 (Artwork G)
 - ① Actuator #1 extend
 - ② Actuator #1 retract
 - 3 Actuator #1 & #2 extend
 - 4 Actuator #1 & #2 retract
 - (5) Actuator #2 extend
 - 6 Actuator #2 retract
 - ② Actuator #3 extend
 - 8 Actuator #3 retract
 - Actuator #4 extend
- 10 Actuator #4 retract



▶ Definition 4 (Artwork L)



- Definition 4 (Artwork L)
 - ① Actuator #1 extend
 - ② Actuator #1 retract
 - 3 Actuator #1 & #2 extend
 - 4 Actuator #1 & #2 retract
 - (5) Actuator #2 extend
 - 6 Actuator #2 retract
 - 7) Actuator #3 & #4 extend
- (8) Actuator #3 & #4 retract
- Actuator #3 extend & #4 retract
- 10 Actuator #3 retract & #4 extend



Remarks:

* When releasing the button, actuator stops and LED indicator turns off immediately.

